


- | | |
|---------------------------------|-------------------------------------|
| 1 Ball valve | 21 To be ordered separately |
| 4 Safety valve | 24 Delivered loose with unit |
| 6 Thermostatic/non-return valve | 26 Manometer |
| 7 Thermostatic valve | 31 Differential pressure controller |
| 9 Strainer | 38 Expansion tank |
| 10 Circulator pump | 41 Fitting piece, energy meter |
| 14 Sensor pocket, energy meter | 42 Safety valve/non-return valve |
| 18 Thermometer | 48 Air escape, manual |
| 20 Filling/drain valve | 72 IHPT |

 Gemina • Termix Navervej 15-17 DK 7451 Sunds Tlf.+4597141444 Fax+4597141159 mail@termix.dk	Contr.: BQN 13.04.10	Date: 18.07.08	Sign: BLJ
	Drwg. no.: VVX-I		
Title: Termix VVX -I T06 Målerpasstykke i retur			
Principdiagram Fjernvarmestation			
	Rev:	Date:	Sign.: