


- A Heat exchanger
- D Hot water tank
- F Electronic controller
- 1 Ball valve
- 2 Single check valve
- 4 Safety valve
- 9 Strainer
- 10 Circulator pump
- 11 Domestic hot water pump
- 16 Outdoor sensor
- 18 Thermometer

- 19 Surface sensor
- 20 Filling/drain valve
- 23 Ball valve
- 24 Delivered loose with unit
- 26 Manometer
- 27 Actuator
- 29 2-way motorized valve
- 31 Differential pressure controller
- 44 Immersion sensor
- 48 Air escape, manual

Obs:
 Gemina Termix recommends the mounting of balancing valves on the main central heating pipes and on the central heating return pipe directly in front of the district heating unit.



	Gemina • Termix	Contr.: xx xx xx xx	Date: xx xx xx	Sign: xxx
	Navervej 15-17 DK 7451 Sunds Tlf.+4597141444 Fax+4597141159 mail@termix.dk	Drwg. no.: VX 20E UK		
Title: Termix Compact 20E VX With out fitting piece energy meter				
Diagram District Heating station				
	Rev:	Date:	Sign.:	